

## N2 and XT BUS Communication

User Manual

March 2006  
Supersedes January 2006



**VSD IntelliPass**



**VSD Open**



**VSD Enclosed IntelliPass w/DX-9100**



March 2006

## Important Notice – Please Read

The product discussed in this literature is subject to terms and conditions outlined in Johnson Controls selling policies. The sole source governing the rights and remedies of any purchaser of this equipment is the relevant Johnson Controls selling policy.

NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OR WARRANTIES ARISING FROM COURSE OF DEALING OR USAGE OF TRADE, ARE MADE REGARDING THE INFORMATION, RECOMMENDATIONS AND DESCRIPTIONS CONTAINED HEREIN. In no event will Johnson Controls or Eaton Electrical Inc. be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein.

The information contained in this manual is subject to change without notice.

Cover Photo: Johnson Controls VSD Series Drives.

## Table of Contents

<b>LIST OF FIGURES</b> .....	iii
<b>LIST OF TABLES</b> .....	iii
<b>SAFETY</b> .....	iv
Definitions and Symbols .....	iv
Hazardous High Voltage .....	iv
<b>CHAPTER 1 — OVERVIEW</b> .....	1-1
Introduction .....	1-1
Specifications .....	1-1
<b>CHAPTER 2 — BOARD LAYOUT AND CONNECTIONS</b> .....	2-1
VS-OPTNX Communication Board .....	2-1
<b>CHAPTER 3 — INSTALLATION</b> .....	3-1
Making the Ground Connection .....	3-1
Bus Terminal Resistors .....	3-3
LED Indications .....	3-4
Installing the VS-OPTNX Communication Board .....	3-5
<b>CHAPTER 4 — COMMISSIONING</b> .....	4-1
Fieldbus Board Parameters .....	4-1
RS-485 Communication Parameters .....	4-1
<b>CHAPTER 5 — JOHNSON CONTROLS METASYS N2 PROTOCOL</b> .....	5-1
Overview .....	5-1
N2 Point Map .....	5-3
<b>CHAPTER 6 — JOHNSON CONTROLS METASYS XT BUS PROTOCOL</b> .....	6-1
DX-9100 XT Bus .....	6-1
XT Bus Point Map .....	6-8
<b>CHAPTER 7 — COMMUNICATION BOARD FAULT TRACKING</b> .....	7-1
<b>APPENDIX A — PROCESS DATA</b> .....	A-1
Process Data OUT (Slave → Master) .....	A-1

March 2006

## List of Figures

Figure 2-1: Option Board VS-OPTNX Communication Board .....	2-1
Figure 3-1: Cable Stripping .....	3-1
Figure 3-2: Inserting the Data Cables .....	3-1
Figure 3-3: Grounding the Communication Cable .....	3-2
Figure 3-4: Stripping the Communication Cables .....	3-2
Figure 3-5: Grounding the Communication Cable .....	3-3
Figure 3-6: Using Jumper X4 to Set the Bus Termination .....	3-3
Figure 3-7: LED Indications on the Communication Board .....	3-4
Figure 4-1: Communication Status .....	4-3
Figure 6-1: Define VSD Analog Points by Selecting the 6AI, 2AO XT Module .....	6-2
Figure 6-2: Assign User Names and the Hardware Address for the XT Module .....	6-2
Figure 6-3: Define VSD Digital Points by Selecting the 4DI, 4DO XT Expansion Module .....	6-3
Figure 6-4: Assign User Names for the XT Expansion Module .....	6-3
Figure 6-5: Define All of the VSD/XT Analog Inputs as "Active" .....	6-4
Figure 6-6: Define the VSD/XT Active Analog Inputs as Noted in Table 6-1 .....	6-4
Figure 6-7: Define the VSD/XT Digital Inputs as Noted in Table 6-3 .....	6-5
Figure 6-8: Assign User Names and Define the VSD/XT Analog Outputs as Noted in Table 6-2 .....	6-5
Figure 6-9: Define the VSD/XT Digital Outputs as ON/OFF Type .....	6-6
Figure 6-10: Assign User Names for the VSD/XT Digital Outputs as Noted in Table 6-4 .....	6-6
Figure 6-11: After Saving the File — Download the DX and XT from the "Action" Menu .....	6-7

## List of Tables

Table 1-1: Specifications .....	1-1
Table 2-1: VS-OPTNX Bus Connector Signals .....	2-1
Table 3-1: Communication Board Status LED (BS) — YELLOW .....	3-4
Table 3-2: Fieldbus Status LED (FS) — GREEN .....	3-4
Table 3-3: Installing the VS-OPTNX Communication Board .....	3-5
Table 4-1: Changing the N2/XT Bus Board Commissioning Parameter Values .....	4-1
Table 4-2: Communication Message Indications .....	4-3
Table 5-1: Analog Inputs (AI) .....	5-3
Table 5-2: Binary Inputs (BI) .....	5-4
Table 5-3: Analog Outputs (AO) .....	5-4
Table 5-4: Binary Outputs (BO) .....	5-5
Table 5-5: Internal Integers (ADI) .....	5-5
Table 6-1: Analog Inputs (AI) .....	6-8
Table 6-2: Analog Outputs (AO) .....	6-8
Table 6-3: Digital Inputs (DI) .....	6-8
Table 6-4: Digital Outputs (DO) .....	6-8
Table 7-1: Communication Board Faults .....	7-1
Table 7-2: VSD Response to Faults .....	7-1
Table A-1: Fieldbus Parameters — M1 → G1.9 .....	A-1

## Safety

### Definitions and Symbols



#### WARNING

This symbol indicates high voltage. It calls your attention to items or operations that could be dangerous to you and other persons operating this equipment. Read the message and follow the instructions carefully.



This symbol is the "Safety Alert Symbol." It occurs with either of two signal words: CAUTION or WARNING, as described below.



#### WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.



#### CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage to the product. The situation described in the CAUTION may, if not avoided, lead to serious results. Important safety measures are described in CAUTION (as well as WARNING).

### Hazardous High Voltage



#### WARNING

Motor control equipment and electronic controllers are connected to hazardous line voltages. When servicing drives and electronic controllers, there may be exposed components with housings or protrusions at or above line potential. Extreme care should be taken to protect against shock.

Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case an emergency occurs. Disconnect power before checking controllers or performing maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on electronic controllers or rotating machinery.

March 2006

## Chapter 1 — Overview

### Introduction

The Johnson Controls VSD Series Drives powered by Cutler-Hammer® technology from Eaton's electrical business can be controlled, monitored and programmed from a host system via Johnson Controls N2 or XT BUS communication protocols with the addition of the VS-OPTNX RS-485 Communication Option Board.

If you purchase your Communication Board separate from the drive, please note that it must be installed in slot D or E on the control board of the VSD Series drive.

### Specifications

**Table 1-1: Specifications**

Item	Specification
<b>Communication Board Connections</b>	
Interface	VS-OPTNX: Pluggable connector (5.08 mm)
Data Transfer Method	RS-485, half-duplex
Communication Bus	3-wire (Twisted pair + Reference) shield optional <sup>①</sup>
Electrical Isolation	500V DC
<b>Communications</b>	
Johnson Controls N2 Bus	As described in Metasys N2 System Protocol Specification
Johnson Controls XT Bus	As described in Metasys System 9100 Protocol Specification
Baud Rate	9600 baud
Addresses	1 to 247
<b>Environment</b>	
Ambient Operating Temperature	14 to 131°F (-10 to 55°C)
Storage Temperature	-40 to 140°F (-40 to 60°C)
Humidity	<95%, non-condensing
Altitude	Max. 3280 ft. (1000m)
Vibration	0.5G at 9 to 200 Hz
<b>Safety</b>	
Standards	Fulfils EN 50178 standard
Certification	CE, UL

<sup>①</sup> The N2/XT Bus is a "daisy chain" communications line. It consists of three wires for the following signals: +, -, and Common. The + and - lines carry the actual data signals. The Common line provides a reference so that each connected device is capable of electrically receiving and transmitting data by creating a common voltage reference among all the devices connected together over the communication bus. Three conductors are required. It is important that the + and - lines are twisted together, which allows most induced noise (common-mode noise) from external sources to affect both lines equally, thereby canceling the noise. In most installations, the communication bus works fine with unshielded cable. However, in noisy environments, shielded twisted wire must be used.






March 2006

## Chapter 2 — Board Layout and Connections

The VS-OPTNX RS-485 Communication Board is connected to the communications bus through a 5-pin pluggable bus connector.

Communication with the control board of the drive takes place through the standard Interface Board Connector (see **Figure 2-1**).

### VS-OPTNX Communication Board





**Figure 2-1: Option Board VS-OPTNX Communication Board**

**Table 2-1: VS-OPTNX Bus Connector Signals**

Signal	Connector	Description
SHLD ①	1 ①	Shield
VP	2	Supply voltage – plus 5V (not used)
-	3	Receive/Transmit data – minus (N2-/RT-)
+	4	Receive/Transmit data – plus (N2+/RT+)
COM	5	Bus Common (REF/COM)

① This pin (1) can be used to bypass the cable shield to the next slave.

**ON**  X4 jumper is the 120Ω termination resistor. Set X4 jumper to ON only if the Johnson Controls N2 Protocol is selected and the drive is the last device on the network. N/A for XT bus communication.

**OFF**  X1 jumper has no effect on VS-OPTNX board.



March 2006


## Chapter 3 — Installation

### Making the Communication Bus and Ground Connections

#### *Terminating the Ground Wire*


**Note:** Normally, the option board has already been installed in slot D or E of the control board. It is not necessary to detach the whole board to connect the communication bus and ground the bus cable shield. Just detach the terminal block.

1. Strip about 2 in. (5 cm) of the communication cable and cut off the gray cable shield. Remember to do this for both bus cables (except for the last device). See **Figure 3-1**.
2. Strip the individual conductors at about 0.2 in (0.5 cm) to fit in the terminals. See **Figure 3-1**.



**Figure 3-1: Cable Stripping**

3. Insert the data cables into terminals #3 (-), #4 (+) and #5 (Com.).




**Figure 3-2: Inserting the Data Cables**

**Grounding by Clamping the Cable to the Converter Frame**

This method of grounding is the most effective, and especially recommended when the distances between the devices are relatively short.

Strip the communication cable so that it can be secured to the drive frame with the grounding clamp.




**Figure 3-3: Grounding the Communication Cable**

**Grounding Only One Point on the Net**

In this method of grounding, the shield is connected to ground only at the last device on the network. Other devices on the network just bypass the shield.

1. Strip about 2 in. (5 cm) of the communication cable and cut off the gray cable shield.
2. Leave no more than 1/4 in. (1 cm) of the cable outside the terminal block and strip the data cables at about 0.5 cm to fit in the terminals. See **Figure 3-4**.



**Figure 3-4: Stripping the Communication Cables**

March 2006


3. Secure the communication cable to the drive frame with the grounding clamp as shown in **Figure 3-5**.



**Figure 3-5: Grounding the Communication Cable**

## Bus Terminal Resistors


If the VS-OPTNX Option Card is programmed for N2 communication and it is the last device on the network, the bus termination must be set to ON. Use jumper X4 (set to the ON position for termination). See **Figure 3-6**.



**Figure 3-6: Using Jumper X4 to Set the Bus Termination**

## LED Indications

The two LED indicators next to the connector show the present status of the Communication Board (yellow) and the Fieldbus Module (green).



**Figure 3-7: LED Indications on the Communication Board**

**Table 3-1: Communication Board Status LED (BS) — YELLOW**

LED is:	Meaning:
OFF	Option board not activated
ON	Option board in initialization state waiting for activation command from the Variable Speed Drive (VSD)
Blinking fast (once/sec)	Option board is activated and in RUN state Option board is ready for external communication
Blinking slow (once/5 secs)	Option board is activated and in FAULT state Internal fault of option board

**Table 3-2: Fieldbus Status LED (FS) — GREEN**

LED is:	Meaning:
OFF	Fieldbus module is waiting for parameters from the VSD No external communication
ON	Fieldbus module is activated Parameters received and module activated Module is waiting for messages from the bus
Blinking fast (once/sec)	Module is activated and receiving messages from the bus
Blinking slow (once/5 secs)	Module is in FAULT state No messages from Master within the watchdog time Bus broken, cable loose or Master off-line

March 2006

## Installing the VS-OPTNX Communication Board

**Table 3-3: Installing the VS-OPTNX Communication Board**







Procedure	Illustration
1. Remove the cable cover.	
2. Open the cover of the control unit.	
3. Install the VS-OPTNXC2 option board in slot D or E on the control board of the VSD. Make sure that the grounding plate (see below) fits tightly in the clamp.	 

Table 3-3: Installing the VS-OPTNX Communication Board, continued

Procedure	Illustration
4. Make a sufficiently wide opening for your cable by cutting the cover grid as wide as necessary.	
5. Close the cover of the control unit and the cable cover.	



March 2006

## Chapter 4 — Commissioning

### Fieldbus Board Parameters

The VS-OPTNX RS-485 Communication board is commissioned with the control keypad by selecting values for the appropriate parameters in the Expander board menu M6.

#### Expander Board Menu (M6)

The Expander board menu makes it possible for the user, (1) to see what expander boards are connected to the control board and (2) to view and edit the parameters associated with the expander board. See the step-by-step procedure to commission the RS-485 communication board below.















### RS-485 Communication Parameters



**Table 4-1: Changing the N2/XT Bus Board Commissioning Parameter Values**










#	Name	Default	Range	Description
1	Communication Protocol	1	1 – N2 Bus 2 – XT Bus 3 – SA Bus	Metasys N2 bus communication Metasys DX-9100 XT bus communication Metasys MS/TP BACnet Communications (future)
2	Slave Address	1	1...247	
3	Communication Timeout	10	0 – OFF 1 – 300 s	See <b>Communication Timeout</b> on <b>Page 4-2</b>

The parameters of every device must be set before connecting to the bus. The parameter "SLAVE ADDRESS" must be the same as programmed in the master configuration. (N2 Supervisory System or DX 9100 device.)














#### Perform the Following Steps to Commission the RS-485 Communication Board

- From Operate Menu   to
- Programing Press 
-  to M6 (Expander boards / G1-G5) 
-  to G6.4 (D:OPTCC / G1-G2)  or G6.5 (E:OPTCC / G1-G2) 
- G6.4.1 (Parameters P1-P3)  or G6.5.1 (Parameters P1-P3)
- P6.4.1.1 or P6.5.1.1 (Comm. Protocol)  N2  , or  XT  

**Note:** If... G6.4 (Slot D: or E: = OPTC2) and P6.4.1.1 or P6.5.1.1 (Comm. Protocol)  ModBus, or  N2, the RS-485 card in the drive is the VS-OPTC2 comm. card not the VS-OPTNX comm. card. The RS-485 comm. card can be reprogrammed with the VS-OPTNX firmware using the 9000X Load software available on the Johnson Controls Portal (or the Exchange website). See the notes on **Page 4-2** or contact JCI Field Support Center for further information.

- P6.4.1.2 or P6.5.1.2 (Slave Address)  1 to 247  
- P6.4.1.3 or P6.5.1.3 (Comm. Timeout)  0 to 10 seconds 
-  To Main Menu
-   to M8 (Operate Mode Press  )

**Procedure to Check the RS-485 Communication Software Revision**

- From Operate Menu   to
- Programing Press 
-  to M5 (System Menu / S1 – S11) 
-  to S5.8 (System Info / I1 – 17) 
-  to S5.8.6 (Expander boards / E1 – E5) 
-  to E5.8.6.4 (D:OPTCC / E1 – E2)  or E5.8.6.5 (E:OPTCC / E1 – E2) 
-  to E5.8.6.4.2 (Program version), or E5.8.6.5.2 (Program version)

**10610.6** = VS-OPTNX software (N2/XT) standard for VSD Series drives (No further action needed).

If the comm. card revision displays ...

**10605.3** = VS-OPTC2 (pre-release software N2/XT) or ...

**10514.15** = VS-OPTC2 software (ModBus/N2) standard for Eaton drives (Perform the following steps)

**IMPORTANT**

The RS-485 card must be in option card slot E when running the C2toCC.exe program.

1. Run the executable file "C2toCC.exe" that is required to convert the ID of the RS-485 card so the drive will recognize the comm. card as the VS-OPTNX.
2. Download the System Software (SVX00031V015.vcn).
3. Download the JCI Application Wizard software (JCX0001V215.vcn).
4. Download the RS-485 communication card with the N2/XT protocol file (NXOPTC2\_10610V006.vcn).

Following these 5-steps will insure your drive is operating with the latest software revisions.

**Note:** Skip Steps 2 and 4 if the VSD Series Drive order was placed on/after January 13, 2006.


**Communication Timeout**

The RS-485 communication board initiates a communication error if communication is broken for as long as defined by Communication Timeout. Communication Timeout is disabled when given the value **0**.

March 2006

**Communication Status**

To see the present status of the communication board, enter the Communication status page from the Monitor menu (G6.4.2). See **Figure 4-1** and **Table 4-2**.

**Figure 4-1: Communication Status****Table 4-2: Communication Message Indications**

Messages	Indications
<b>Good messages</b>	
0 – 999	Number of messages received without communication errors
<b>Error messages</b>	
0 – 64	Number of messages received with CRC or parity errors



March 2006

## Chapter 5 — Johnson Controls Metasys N2 Protocol

### Overview

The N2 Interface provides:

- Direct control of Drive (e.g. Run, Stop, Direction, Speed reference, Fault reset)
- Full access to necessary parameters
- Monitoring of Drive status (e.g. Output frequency, Output current, Fault code)
- In stand-alone operation, or if the polling is stopped, the overridden values are released after 10 minutes.

#### **Analog Input (AI) Features**

All Analog Input (AI) points have the following features:

- Support Change of State (COS) reporting based on high and low warning limits.
- Support Change of State (COS) reporting based on high and low alarm limits.
- Support Change of State (COS) reporting based on override status.
- Always considered reliable and never out of range.
- Writing of alarm and warning limit values beyond the range that can be held by the drive's internal variable will result in having that limit replaced by the "Invalid Float" value even though the message is acknowledged. The net result will be the inactivation of the alarm or warning (the same as if the original out of range value was used).
- The N2 system should be set up to disallow overriding AI points or have an alarm condition activated when a AI point is overridden. Overriding is supported from the standpoint that the "Override Active" bit will be set and the value reported to the N2 network will be the overridden value. However, the value in the drive remains unchanged.
- Overriding an AI point with a value beyond the limit allowed by the drive's internal variable will result in an "Invalid Data" error response and the override status and value will remain unchanged.

#### **Binary Input (BI) Features**

All Binary Input (BI) points have the following features:

- Support Change of State (COS) reporting based on current state.
- Support Change of State (COS) reporting based on alarm condition.
- Support Change of State (COS) reporting based on override status.
- Always considered reliable.

The N2 system should be set up to disallow overriding BI points or have an alarm condition activated when a BI point is overridden. Overriding is supported from the standpoint that the "Override Active" bit will be set and the value reported to the N2 network will be the overridden value. However, the value in the drive remains unchanged.

**Analog Output (AO) Features**

All Analog Output (AO) points have the following features:

- Support Change of State (COS) reporting based on override status.
- Always considered reliable.
- Overriding of the AO points is the method used to change a value. Overriding an AO point with a value beyond the limit allowed by the drive's internal variable will result in an "Invalid Data" error response and the override status and value will remain unchanged. If the overridden value is beyond the drive's parameter limit but within the range that will fit in the variable, an acknowledge response is given and the value will be internally clamped to its limit.
- An AO point override copies the override value to the corresponding drive parameter. This is the same as changing the value on the drive keypad. The value is nonvolatile and will remain in effect when the drive is turned off and back on. It also remains at this value when the N2 network "Releases" the point. The N2 system always reads the current parameter value.

**Note:** The N2 system will not poll the AO point when it is being overridden. In this case, the N2 system will not notice a change in value if the change is made via the keypad. To avoid this scenario, set the point up as a "local control" type and release it once it has been overridden. In this way, the N2 system will monitor the value when not being overridden.

**Binary Output (BO) Features**

All Binary Output (BO) points have the following features:

- Support Change of State (COS) reporting based on override status.
- Always considered reliable.
- Overriding BO points control the drive. These points are inputs commands to the drive.

When released, the drive's internal value remains at its last overridden value.

**Internal Integer (ADI) Features**

All Internal Integer (ADI) points have the following features:

- Do not support Change of State (COS) reporting.
- Can not be overridden.

March 2006

## N2 Point Map

### Analog Input (AI) Point Map

**Table 5-1: Analog Inputs (AI)**

NPT	NPA	Description	Units	Note
AI	1	Speed Setpoint	Hz	2 decimals
AI	2	Output Speed	Hz	2 decimals
AI	3	Motor Speed	Rpm	0 decimal
AI	4	Load (power)	%	1 decimal
AI	5	Megawatt Hours	MWh	Total Counter
AI	6	Motor Current	A	2 decimal
AI	7	Bus Voltage	V	0 decimal
AI	8	Motor Volts	V	1 decimal
AI	9	Heatsink Temperature	° C	0 decimal
AI	10	Motor Torque	%	1 decimal
AI	11	Operating Days	Day	0 decimal
AI	12	Operating Hours	Hour	0 decimal
AI	13	Kilowatt Hours	kWh	Trip Counter
AI	14	Torque Reference	%	1 decimal
AI	15	Motor Temperature Rise	%	1 decimal
AI	16	PID Feedback (Process Variable) (Dependent on PID Application)	" wc/Pa " wc/Pa psi/kPa °F/°C %	— Duct Static — Building Static — Pressure — Temperature — Generic
AI	17	Open (future use)	—	—
AI	18	FBDataOut1Sel <sup>①</sup>	—	0 decimal
AI	19	FBDataOut2Sel <sup>①</sup>	—	0 decimal
AI	20	FBDataOut3Sel <sup>①</sup>	—	0 decimal
AI	21	FBDataOut4Sel <sup>①</sup>	—	0 decimal
AI	22	FBDataOut5Sel <sup>①</sup>	—	0 decimal
AI	23	FBDataOut6Sel <sup>①</sup>	—	0 decimal
AI	24	FBDataOut7Sel <sup>①</sup>	—	0 decimal
AI	25	FBDataOut8Sel <sup>①</sup>	—	0 decimal

<sup>①</sup> These analog inputs are application specific. See **Table A-1** on **Page A-1**.

**Binary Input (BI) Point Map****Table 5-2: Binary Inputs (BI)**

NPT	NPA	Description	0 =	1 =
BI	1	Ready	Not Ready	Ready
BI	2	Run	Stop	Run
BI	3	Direction	Clockwise	Counterclockwise
BI	4	Faulted	Not Faulted	Faulted
BI	5	Warning	Not Warning	Warning
BI	6	Ref. Frequency reached	False	True
BI	7	Motor running at zero speed	False	True
BI	8	Digital Input Interlock	False	True
BI	9	Bypass Mode Active	False	True
BI	10	Digital Input Fire Mode	False	True
BI	11	Hand Control Mode	False	True
BI	12	Auto Control Mode	False	True
BI	13	Control Mode OFF	False	True

**Analog Output (AO) Point Map****Table 5-3: Analog Outputs (AO)**

NPT	NPA	Description	Units	Note
AO	1	Comms Speed	%	2 decimal
AO	2	Current Limit	A	2 decimal
AO	3	Minimum Speed	Hz	2 decimal
AO	4	Maximum Speed	Hz	2 decimal
AO	5	Accel Time	s	1 decimal
AO	6	Decel Time	s	1 decimal
AO	7	FB PI Setpoint <sup>①</sup>	%	2 decimal
AO	8	FB Actual Value <sup>①</sup>	%	2 decimal

<sup>①</sup> These analog outputs are sent to the drive and require Parameter 1.1.15 St Pt source auto to be set to "Fieldbus" for AO-7 and Parameter 1.1.17 PI-Input source to be set to "Fieldbus" for AO-8.



March 2006

**Binary Output (BO) Point Map****Table 5-4: Binary Outputs (BO)**

NPT	NPA	Description	0 =	1 =
BO	1	Comms Start/Stop	Stop	Start
BO	2	Comms Forward/Reverse	Forward	Reverse
BO	3	Comms Reset Fault	N/A	Reset
BO	4	Enable Bypass FB FixedControlWord Bit_3 ①	Disable	Enable
BO	5	Activate FB.DI-3 FBFixedControlWord Bit_4 ①	OFF	ON
BO	6	Activate FB.DI-4 FBFixedControlWord Bit_5 ①	OFF	ON
BO	7	Activate FB.DI-5 FBFixedControlWord Bit_6 ①	OFF	ON
BO	8	Activate FB.DI-6 FBFixedControlWord Bit_7 ①	OFF	ON
BO	11	Pass Through RO-1	OFF	ON
BO	12	Pass Through RO-2	OFF	ON
BO	13	Pass Through DO-1	OFF	ON
BO	14	Activate Fire Mode	OFF	ON
BO	15	Comms PM Setback	OFF	ON

① These binary outputs are application specific. These can be used to override DI-2 through DI-6 to the "ON" or "Activated" position.

**Pass Through Digital and Relay Outputs**

If controlling digital or relay outputs through the fieldbus, set parameters P1.3.6 – P1.3.8 "Not Used" (#0).

**Internal Integer (ADI) Point Mapping****Table 5-5: Internal Integers (ADI)**

NPT	NPA	Description	Units
ADI	1	Active Fault Code	—



March 2006

## Chapter 6 — Johnson Controls Metasys XT Bus Protocol

### DX-9100 XT Bus

The Metasys DX-9100 Extended Digital Controller can be configured to provide precise Direct Digital Control (DDC) as well as Programmed Logic Control (PLC) for a variety of HVAC applications. The DX-9100 can be used as a stand-alone controller or it can be connected to a Metasys Supervisory System over the N2 communication bus. See the Metasys System 9100 Technical Guide (LIT-6364000) for the complete description of the DX-9100 operation.

The XT bus communication protocol was incorporated into the VS-OPTNX communication card to allow the VSD Series Drive to operate with the Johnson Controls DX-9100 Controller as part of the Enclosed Drive package solution or to interface with a DX-9100 control panel. The interface provides the following benefits:

- Direct control of the drive through the DX-9100 controller (over the XT bus) using the standard programming tools (GX-9100 Software Configuration and the DX Commissioning Point Template Program).
- Full access to necessary parameters for control and monitoring the drive (e.g. Run Command, Speed Reference, Fault Reset, Output Frequency, Motor Speed, and Fault Codes).

The DX-9100 control algorithms and input/output point assignments are defined using the GX-9100 Graphical Configuration Software. (See: *GX9100 Software Configuration Guide*, Lit-6364060) This software is also used to identify the "virtual" VSD Series Drive parameters, just as if you were programming the XT bus to define XT Extension Modules for the purpose of expanding I/O capability. Simply select the "6AI, 2AO" XT module from the GX-9100 program module drop-down menu (see **Figure 6-1**), followed by selecting the "4DI, 4DO" EXP module (see **Figure 6-11**).

Once the XT modules are selected in the GX-9100 graphical software, refer to the XT bus point map (**Tables 6-1 to 6-4**) for the XT input/output definition that aligns with the VSD Series Drive parameters.

See Tables 14 and 15 in the N2 *Integration with the NAE Technical Bulletin* (LIT-1201683) for complete details on mapping DX-9100 points to NAE objects (including tag names, item descriptions, which points are commandable, etc.).

The "Hardware Address" assigned to the XT Extension Module is the "Slave Address" that will be entered when programming the RS-485 communication parameters in the VSD Series drive (see Chapter 4 – Commissioning).

**Note:** A sample DX-9100/XT configuration file of the virtual XT-9100 extension module and XP-9102/XP-9104 expansion modules is available for download from the Johnson Controls portal website at [my.johnsoncontrols.com](http://my.johnsoncontrols.com) under > Products: Variable Speed Drives. On ABCS *Exchange*, visit Exchange Site > Products > Product Families > Variable Speed Drives.

This will provide the end-user with a starting point for configuring the DX-9100/XT application using the GX9100 Graphical Programming Tool.

March 2006




Figure 6-1: Define VSD Analog Points by Selecting the 6AI, 2AO XT Module






Figure 6-2: Assign User Names and the Hardware Address for the XT Module

March 2006

**Figure 6-3: Define VSD Digital Points by Selecting the 4DI, 4DO XT Expansion Module****Figure 6-4: Assign User Names for the XT Expansion Module**

March 2006




Figure 6-5: Define All of the VSD/XT Analog Inputs as “Active”






Figure 6-6: Define the VSD/XT Active Analog Inputs as Noted in Table 6-1

March 2006

**Figure 6-7: Define the VSD/XT Digital Inputs as Noted in Table 6-3****Figure 6-8: Assign User Names and Define the VSD/XT Analog Outputs as Noted in Table 6-2**




Figure 6-9: Define the VSD/XT Digital Outputs as ON/OFF Type





Figure 6-10: Assign User Names for the VSD/XT Digital Outputs as NOTed in Table 6-4



March 2006



**Figure 6-11: After Saving the File — Download the DX and XT from the “Action” Menu**

## XT Bus Point Map

### Analog Input (AI) Point Map

**Table 6-1: Analog Inputs (AI)**

NPT/NPA	Description	Units	Default
XTxAI1	Speed Setpoint	%	N.A.
XTxAI2	Output Speed	%	N.A.
XTxAI3	Frequency Output	Hz	N.A.
XTxAI4	Motor Speed	RPM	N.A.
XTxAI5	Fault Code		N.A.
XTxAI6	Not Used		

### Analog Output (AO) Point Map

**Table 6-2: Analog Outputs (AO)**

NPT/NPA	Description	Units	Default
XTxAO7	Reference (Speed) Command	%	20%
XTxAO8	Not Used		

### Digital Input (DI) Point Map

**Table 6-3: Digital Inputs (DI)**

NPT/NPA	Description	Units	Note
XTxDI1	Drive Running	On/Off	1=On=Drive Running
XTxDI2	Drive Faulted	On/Off	1=On=Faulted
XTxDI3	Hand (Manual) Mode	On/Off	1=On=Hand Mode
XTxDI4	Auto Mode	On/Off	1=On=Auto Mode

### Digital Output (DO) Point Map

**Table 6-4: Digital Outputs (DO)**

NPT/NPA	Description	Units	Note <sup>①</sup>
XTxDO1	Run (Start) Command	On/Off	1=On=Run
XTxDO2	Reset Fault Command	On/Off	1=On=Reset Fault
XTxDO3	Bypass Mode	On/Off	1=On=Bypass Enable <sup>②</sup>
XTxDO4	Not Used		

<sup>①</sup> Default = 0.

<sup>②</sup> Requires the "Run" Command = On to activate the bypass command.

The Reset Fault DO point must be commanded to the OFF state after each occurrence of resetting a fault condition.

March 2006

## Chapter 7 — Communication Board Fault Tracking

The table below presents the faults related to System Level errors. For more fault code information, see also *VSD Series User Manual* (Fault Tracking Section).

**Table 7-1: Communication Board Faults**

Fault Code	Fault	Possible cause	Possible solutions
37	Device change	Option board changed	Reset
38	Device added	Option board added	Reset
39	Device removed	Option board removed	Reset
40	Device unknown	Unknown option board	Check the installation. If installation is correct contact Johnson Controls Technical Support.
53	Fieldbus fault	The data connection between the Modbus Master and the Modbus option board is broken	Check the installation. If installation is correct contact Johnson Controls Technical Support.
54	Slot fault	Defective option board or slot	Check the board and slot. Contact Johnson Controls Technical Support.

You can define with parameters how the AFD shall react to certain faults:

**Table 7-2: VSD Response to Faults**

Code	Parameter	Min.	Max	Unit	Step	Default	Note
P2.7.22	Response to fieldbus fault	0	3		1	0	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting
P2.7.23	Response to slot fault	0	3		1	0	0=No response 1=Warning 2=Fault,stop acc. to 2.4.7 3=Fault,stop by coasting



March 2006

## Appendix A — Process Data

### Process Data OUT (Slave → Master)

The fieldbus master can read the VSD's actual values using process data variables.

Remote Input, Generic PI, Duct Static, Building Static, Pressure Control and Temperature Control Applications use process data as follows:

**Table A-1: Fieldbus Parameters — M1 → G1.9**

Code	Parameter	Min.	Max.	Unit	Default	ID Number	Description
P1.9.1	FB Data Out1 Sel	0	10000		1 <sup>①</sup>	1001	Fieldbus process data output 1 selection. Default = Actual Speed
P1.9.2	FB Data Out2 Sel	0	10000		5 <sup>①</sup>	1002	Fieldbus process data output 2 selection. Default = Motor Current
P1.9.3	FB Data Out3 Sel	0	10000		8 <sup>①</sup>	1003	Fieldbus process data output 3 selection. Default = Motor Voltage
P1.9.4	FB Data Out4 Sel	0	10000		7 <sup>①</sup>	1004	Fieldbus process data output 4 selection. Default = Motor Power
P1.9.5	FB Data Out5 Sel	0	10000		9 <sup>①</sup>	1005	Fieldbus process data output 5 selection. Default = DC-Link Voltage
P1.9.6	FB Data Out6 Sel	0	10000		20 <sup>①</sup>	1006	Fieldbus process data output 6 selection. Default = Application Status Word (Variable:AppIStatusWord) <b>b0</b> = Drive Ready <b>b1</b> = Run Enable <b>b2</b> = Drive Running <b>b3</b> = Drive Reversing <b>b4</b> = General Fault <b>b5</b> = General Warning <b>b6</b> = Jogging speed (PM Setback) active <b>b7</b> = Motor Regulator active <b>b8</b> = Output speed supervision indication <b>b9</b> = Setpoint speed supervision indication <b>b10</b> = HAND Control indication <b>b11</b> = AUTO Control indication <b>b12</b> = D-IN Firemode <b>b13</b> = Damper control signal <b>b14</b> = Bypass mode status indication <b>b15</b> = Bypass running

<sup>①</sup> ID number of parameter or variable to be sent over fieldbus. ID 1 – 20 are Monitoring values, Menu 7 (M7).

**Table A-1: Fieldbus Parameters — M1 → G1.9 , continued**

Code	Parameter	Min.	Max.	Unit	Default	ID Number	Description
P1.9.7	FB Data Out7 Sel	0	10000		18 <sup>①</sup>	1007	Fieldbus process data output 7 selection. Default = Active Fault Code
P1.9.8	FB Data Out8 Sel	0	10000		19 <sup>①</sup>	1008	Fieldbus process data output 8 selection. Default = Active Warning Code

<sup>①</sup> ID number of parameter or variable to be sent over fieldbus. ID 1 – 20 are Monitoring values, Menu 7 (M7).

The VSD Series applications have a selector parameter for every Process Data. The monitoring values and drive parameters can be selected using the ID number (see *VSD Series Drives User Manual*, Lit-1201828, Chapter 15 – Description of Parameters, for further definitions).





*Powered by* **Eaton's Cutler-Hammer Technology**

**Controls Group**  
507 E. Michigan Street  
P.O. Box 423  
Milwaukee, WI 53201

© 2006 Johnson Controls  
All Rights Reserved  
Printed in USA  
Code No. LIT-1201829/CPG  
[www.johnsoncontrols.com](http://www.johnsoncontrols.com)  
March 2006